SERVICE KIT & RiteSensor STARTER CABINET

"When new tires are installed, it is recommended to also replace all components that are included in the TPMS valve replacement kit."

Source: U.S. Tire Manufacturers Association https://www.ustires.org/sites/default/files/USTMA_TISB_40.pdf

315 Service Kits & 20 Rite-Sensors® included





B-9073

B-8380

Storage Cabinet contains 24 labeled sliding drawers and measures 24" x 16" x 6" and is suitable for mounting on the wall or bench top.

P/N: RS-2000-CAB02





The 3 Types of replacement kits:



OE Sensor Service Kit

This service kit is for OE TPMS Sensors with Aluminum Valve Stems. The typical kit consists of a hex nut, grommet (seal) valve core and dust cap.

NEVER reuse the existing components! Always replace these items to prevent failure, leaks and corrosion.

ALWAYS use the appropriate tools when assembling and adhere to all torque specifications.



OE Sensor Aluminum Valve Kit

This service kit is for OE TPMS Sensors with replaceable aluminum valves. The typical kit consists of a new valve, grommet (seal), hex nut, valve core, screw and dust cap.

NEVER reuse the existing components! Always replace these items to prevent failure, leaks and corrosion.

ALWAYS use the appropriate tools when assembling and adhere to all torque specifications.



OE Sensor Rubber Valve Kit

This service kit is for OE TPMS Sensors with replaceable rubber valves. The typical kit consists of a new valve, valve core, screw and dust cap.

NEVER reuse the existing components! Always replace these items to prevent failure, leaks and rubber decay.

ALWAYS use the appropriate tools when assembling and adhere to all torque specifications.





- **Single SKU solution**
- Multi-Frequency (315 & 433 MHz)
- Programs in seconds
- Rubber valve stem standard
- Aluminum valve stem available
- Limited lifetime warranty
- RITE-SYNC® seamless process



Sensor Programming and Vehicle Relearn are now ONE SINGLE PROCESS!



