



TPMS

Technical Service Bulletin



Repair Procedure

RP-618-012

Applies To: Lexus main and 2nd TPMS setting

August 21, 2012

Scope of this bulletin:

Some Lexus MMY have the ability to learn two different sets of sensors to the vehicle so the customer can flick a switch when wheels and tires are changed.

Topics covered in this bulletin:

1. About Lexus main and 2nd
2. Where to find main and 2nd toggle switches
3. Setting the switch

1. About Lexus main and 2nd:

The "Main/2nd" switch allows the owner to have two different sets of tires and wheels, with two different sets of sensors and IDs.

IMPORTANT

(NOTE: When writing new sensors to a vehicle with a "Main/2nd" possibility the toggle switch must be on the correct selection, main or 2nd, or the vehicle will have error messages.)

2. Where to find main and 2nd toggle switches:

Lexus has released TSBs of their own on this switch and according to their TSBs the "Main/2nd" toggle switch is located in the glove compartment.

Further Bartec research has found the switch in these other locations:

- RX350 2007 & 2011 behind and under glove box
- GS350 2008 button located back and behind firewall
- ES350 2008 passenger side back floor board

3. Setting the switch:

According to Lexus when the switch is flipped up Main is selected and when flipped down 2nd is selected.